



Application Note for CTPM

Application Note for CTPM

Project name	Touch panel
Document ref	[Document ref]
Version	1.1
Release date	15 Apr,2011
Owner	Lihua
Classification	Confidential
Distribution List	[Distribution list]
Approval	

This document contains information proprietary to FocalTech Systems, Ltd., and may not be reproduced, disclosed or used in whole or part without the express written permission of FocalTech Systems, Ltd.

Copyright © 2011, FocalTech Systems, Ltd

All rights reserved

R3-B4-A, South Area, Shenzhen Hi-Tech Industrial Park,
Shenzhen, Gungdong, P.R. China

ZIP :518057

T +86 755 26588222

F +86 755 26712499

E support@focaltech-systems.com

www.focaltech-systems.com

FocalTech

Revision History

Date	Version	List of changes	Author + Signature
18 Jan, 2010	0.1	Initial draft	Xiaoxu Du
17 Mar,2010	0.2	Add raw data protocol	Xiaoxu Du
22 Mar,2010	0.3	Add system information protocol	Xiaoxu Du
26 Mar,2010	0.4	Add calibration related parameters	Xiaoxu Du
08 May,2010	0.5	Add information to operating mode	Xinming Wang
07 Jul, 2010	0.6	Change Protocol and add information	Yunfeng Yuan
18 Aug, 2010	0.7	Modified to release version	Xiaoxu Du
22 Dec, 2010	0.8	Modify explanation for register 0xA4	Xiaoxu Du
13 Feb, 2011	0.9	Add ten point support Modify mode description	Xiaoxu Du
17 Feb, 2011	1.0	Modify FT5306DE4 typical application schematic	Xiaoxu Du
15 Apr,2011	1.1	Modify FT5206GE1/FT5306DE4/FT5406EE8 Lihua application schematic	Lihua

FocalTech

Table of Contents

1	I ² C Interface	5
1.1	CTPM interface to Host	5
1.2	I ² C Read/Write Interface description	5
1.3	Interrupt signal from CTPM to Host	6
1.4	Wakeup signal from Host to CTPM.....	6
2	CTP Register Mapping.....	6
2.1	Work Mode	7
2.1.1	<i>DEVICE_MODE</i>	11
2.1.2	<i>GEST_ID</i>	11
2.1.3	<i>TD_STATUS</i>	11
2.1.4	<i>TOUCHn_XH (n:1-10)</i>	11
2.1.5	<i>TOUCHn_XL (n:1-10)</i>	12
2.1.6	<i>TOUCHn_YH (n:1-10)</i>	12
2.1.7	<i>TOUCHn_YL (n:1-10)</i>	12
2.1.8	<i>ID_G_THGROUP</i>	12
2.1.9	<i>ID_G_THPEAK</i>	12
2.1.10	<i>ID_G_THCAL</i>	12
2.1.11	<i>ID_G_THWATER</i>	12
2.1.12	<i>ID_G_THTEMP</i>	13
2.1.13	<i>ID_G_THDIFF</i>	13
2.1.14	<i>ID_G_CTRL</i>	13
2.1.15	<i>ID_G_TIMEENTERMONITOR</i>	13
2.1.16	<i>ID_G_PERIODACTIVE</i>	13
2.1.17	<i>ID_G_PERIODMONITOR</i>	13
2.1.18	<i>ID_G_AUTO_CLB_MODE</i>	13
2.1.19	<i>ID_G_LIB_VERSION_H</i>	14
2.1.20	<i>ID_G_LIB_VERSION_L</i>	14
2.1.21	<i>ID_G_CIPHER</i>	14
2.1.22	<i>ID_G_MODE</i>	14
2.1.23	<i>ID_G_PMODE</i>	14
2.1.24	<i>ID_G_FIRMWARE_ID</i>	14
2.1.25	<i>ID_G_STATE</i>	14
2.1.26	<i>ID_G_FT5201ID</i>	15
2.1.27	<i>ID_G_ERR</i>	15
2.1.28	<i>ID_G_CLB</i>	15
2.2	Factory Mode	15
2.2.1	<i>DEVICE_MODE</i>	17
2.2.2	<i>ROW_ADDR</i>	17
2.2.3	<i>CLB</i>	17
2.2.4	<i>ROWDATAN_H</i>	17
2.2.5	<i>ROWDATAN_L</i>	17
3	CTPM Application Introduction	18
3.1	Standard Application information of FT5X06	18
3.1.1	<i>Standard application circuit of FT5206GE1</i>	18
3.1.2	<i>Standard application circuit of FT5306DE4</i>	19
3.1.3	<i>Standard application circuit of FT5406EE8</i>	19
4	Communication between host and CTPM.....	20

FocalTech

4.1	Communication Contents.....	20
4.2	I2C Example Code	20

Terminology

CTP – Capacitive touch panel

CTPM – Capacitive touch panel module

1 I²C Interface

1.1 CTPM interface to Host

Figure 1-1 shows how CTPM communicates with the Host, there are three kind of communication between CTPM and Host, we will introduce each communication in this section.

Transfer the data via I²C

Send interrupt when there is a valid touch

Host send Wakeup signal to CTPM




Figure 1-1 CTPM and Host connection

The Power Supply voltage of CTPM is 2.8V~3.3V, interface supply voltage is 2.8V~3.3V. There are Control Interface and Data Interface. As


Figure 1-1 demonstrates, Serial interface is the data interface, /INT and /WAKE are the control interface. For the detail, please refer to Table 1-1.

Table 1-1 Description for TP module and Host interface


Port Name	Voltage	Polar	Description
Serial interface	2.8~3.3V		Serial interface is for data transfer between Host and CTPM. CTPM support both I2C and SPI interface
/INT	2.8~3.3V	LOW	The interrupt from the CTPM to the Host
/WAKE*	2.8~3.3V	LOW	Wakeup signal from host to the CTPM

1.2 I²C Read/Write Interface description


Write N bytes to I²C slave



Set Data Address



Read X bytes from I²C Slave



1.3 Interrupt signal from CTPM to Host

As for standard CTPM, host need to use both interrupt control signal and serial data interface to get the touch data. There are two kind of method to use interrupt: interrupt trigger and interrupt query.

Here is the timing to get touch data.




Figure 1-2 Interrupt query mode




Figure 1-3 Interrupt trigger mode

Host use general I²C protocol to read the touch data or the information from CTPM . CTPM will send host a interrupt signal when there is a valid touch. Then host can use the serial data interface to get the touch data. If there is no valid touch detected, the /INT will not be pulled up, the host do not need to read the touch data.

NOTE: “valid touch” may have different definition in various systems. For example, in some systems, the valid touch is defined as there is one more valid touch point. But in some other systems, the valid touch is defined as one more valid touch with valid gestures. In usual, /INT will be pulled up when there is a valid touch point, and to be low when a touch finishes.

As for interrupt trigger mode, /INT signal will be low if there is a touch detected. But for per update of valid touch data, CTPM will produce a valid pulse for /INT signal, host can read the touch data periodically according to the frequency of this pulse. In this mode, the pulse frequency is the touch data update frequency.

1.4 Wakeup signal from Host to CTPM

Host can use the Wakeup Signal to wakeup the I²C slave device.

This pin should be connected to GND when flash programming while in normal running mode it should not be connected to GND.

2 CTP Register Mapping

This chapter describes the standard FTS Capacitive Touch Panel products communication registers in address order for each device mode. The most detailed descriptions of the Standard Products communication registers are in the Register Definitions section of each chapter. The device modes are listed in the table below, along

with each mode's register prefix.

Device Mode	Val	Description
Work	000b	Read touch point and gesture
Factory	100b	Read raw data

2.1 Work Mode

In this mode the CTP is fully functional as a touch screen controller. Read and write access address is just logical address which is not enforced by hardware or firmware. Here is the operating mode register map.

Work Mode Register Map

Address	Name	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Host Access			
00h	DEVIDE_MODE		Device Mode[2:0]										
01h	GEST_ID	Gesture ID[7:0]											
02h	TD_STATUS					Number of touch points[3:0]				R			
03h	TOUCH1_XH	1 st Event Flag				1 st Touch X Position[11:8]				R			
04h	TOUCH1_XL	1 st Touch X Position[7:0]											
05h	TOUCH1_YH	1 st Touch ID[3:0]			1 st Touch Y Position[11:8]								
06h	TOUCH1_YL	1 st Touch Y Position[7:0]											
07h													
08h													
09h	TOUCH2_XH	2 nd Event Flag				2 nd Touch X Position[11:8]				R			
0Ah	TOUCH2_XL	2 nd touch X Position[7:0]											
0Bh	TOUCH2_YH	2 nd Touch ID[3:0]			2 nd Touch Y Position[11:8]								
0Ch	TOUCH2_YL	2 nd Touch Y Position[7:0]											
0Dh													
0Eh													
0Fh	TOUCH3_XH	3 rd Event Flag				3 rd Touch X Position[11:8]				R			
10h	TOUCH3_XL	3 rd Touch X Position[7:0]											
11h	TOUCH3_YH	3 rd Touch ID[3:0]			3 rd Touch Y Position[11:8]								
12h	TOUCH3_YL	3 rd Touch Y Position[7:0]											
13h													
14h													

FocalTech

15h	TOUCH4_XH	4 th Event Flag		4 th Touch X Position[11:8]	R
16h	TOUCH4_XL	4 th Touch X Position[7:0]			R
17h	TOUCH4_YH	4 th Touch ID[3:0]		4 th Touch Y Position[11:8]	R
18h	TOUCH4_YL	4 th Touch Y Position[7:0]			R
19h					R
1Ah					R
1Bh	TOUCH5_XH	5 th Event Flag		5 th Touch X Position[11:8]	R
1Ch	TOUCH5_XL	5 th Touch X Position[7:0]			R
1Dh	TOUCH5_YH	5 th Touch ID[3:0]		5 th Touch Y Position[11:8]	R
1Eh	TOUCH5_YL	5 th Touch Y Position[7:0]			R
1Fh					R
20h					R
21h	TOUCH6_XH	6 th Event Flag		6 th Touch X Position[11:8]	
22h	TOUCH6_XL	6 th Touch X Position[7:0]			
23h	TOUCH6_YH	6 th Touch ID[3:0]		6 th Touch Y Position[11:8]	
24h	TOUCH6_YL	6 th Touch Y Position[7:0]			
25h					
26h					
27h	TOUCH7_XH	7 th Event Flag		7 th Touch X Position[11:8]	
28h	TOUCH7_XL	7 th Touch X Position[7:0]			
29h	TOUCH7_YH	7 th Touch ID[3:0]		7 th Touch Y Position[11:8]	
2Ah	TOUCH7_YL	7 th Touch Y Position[7:0]			
2Bh					
2Ch					
2Dh	TOUCH8_XH	8 th Event Flag		8 th Touch X Position[11:8]	
2Eh	TOUCH8_XL	8 th Touch X Position[7:0]			
2Fh	TOUCH8_YH	8 th Touch ID[3:0]		8 th Touch Y Position[11:8]	
30h	TOUCH8_YL	8 th Touch Y Position[7:0]			
31h					
32h					

FocalTech

33h	TOUCH9_XH	9 th Event Flag		9 th Touch X Position[11:8]	
34h	TOUCH9_XL	9 th Touch X Position[7:0]			
35h	TOUCH9_YH	9 th Touch ID[3:0]		9 th Touch Y Position[11:8]	
36h	TOUCH9_YL	9 th Touch Y Position[7:0]			
37h					
38h					
39h	TOUCH10_XH	10 th Event Flag		10 th Touch X Position[11:8]	
3Ah	TOUCH10_XL	10 th Touch X Position[7:0]			
3Bh	TOUCH10_YH	10 th Touch ID[3:0]		10 th Touch Y Position[11:8]	
3Ch	TOUCH10_YL	10 th Touch Y Position[7:0]			
3Dh					
3Eh					
3Fh	Reserved				
...	...				
7Fh	Reserved				
80h	ID_G_THGROUP	valid touching detect threshold.			R/W
81h	ID_G_THPEAK	valid touching peak detect threshold.			R/W
82h	ID_G_THCAL	the threshold when calculating the focus of touching.			R/W
83h	ID_G_THWATER	the threshold when there is surface water.			R/W
84h	ID_G_THTEMP	the threshold of temperature compensation.			R/W
85h					R/W
86h	ID_G_CTRL			Power control mode[1:0]	R/W
87h	ID_G_TIME_ENTER_MONITOR	The timer of entering monitor status			R/W
88h	ID_G_PERIODACTIVE		Period Active[3:0]		R/W
89h	ID_G_PERIOD MONITOR	The timer of entering idle while in monitor status			R/W
8Ah					R/W
8Bh					R/W
8Ch					R/W
8Dh					R/W
8Eh					R/W
8Fh					R/W
90h					R/W

FocalTech

91h			R/W
92h			R/W
93h			R/W
94h			R/W
95h			R/W
96h			R/W
97h			R/W
98h			R/W
99h			R/W
9Ah			R/W
9Bh			R/W
9Ch			R/W
9Dh			R/W
9Eh			R/W
9Fh			R/W
A0h	ID_G_AUTO_CLB_MODE	auto calibration mode	R/W
A1h	ID_G_LIB_VERSION_H	Firmware Library Version H byte	R
A2h	ID_G_LIB_VERSION_L	Firmware Library Version L byte	R
A3h	ID_G_CIPHER	Chip vendor ID	R
A4h	ID_G_MODE	the interrupt status to host	R
A5h	ID_G_PMODE	Power Consume Mode	
A6h	ID_G_FIRMID	Firmware ID	R
A7h	ID_G_STATE	Running State	
A8h	ID_G_FT5201ID	CTPM Vendor ID	R
A9h	ID_G_ERR	Error Code	R
AAh	ID_G_CLB	Configure TP module during calibration in Test Mode	R/W
ABh			R/W
ACh			R/W
ADh			R/W
AEh	ID_G_B_AREA_TH	The threshold of big area	R/W
AFh			R/W
...	...		
FDh	Reserved		
FEh	LOG_MSG_CNT	The log MSG count	R
FFh	LOG_CUR_CHA	Current character of log message, will point to the next character when one character is read.	R

2.1.1 DEVICE_MODE

This register is the device mode register, configure it to determine the current mode of the chip.

Address	Bit Address	Register Name	Description
00h	6:4	Device Mode [2:0]	000b Work Mode 100b Factory Mode – read raw data

2.1.2 GEST_ID

This register describes the gesture of a valid touch.

Address	Bit Address	Register Name	Description
01h	7:0	Gesture ID [7:0]	Gesture ID 0x10 Move UP 0x14 Move Left 0x18 Move Down 0x1C Move Right 0x48 Zoom In 0x49 Zoom Out 0x00 No Gesture

2.1.3 TD_STATUS

This register is the Touch Data status register.

Address	Bit Address	Register Name	Description
02h	3:0	Number of touch points[3:0]	How many points detected. 1-5 is valid.
	7:4		

2.1.4 TOUCHn_XH (n:1-10)

This register describes MSB of the X coordinate of the nth touch point and the corresponding event flag.

Address	Bit Address	Register Name	Description
03h ~ 39h	7:6	Event Flag	00b: Put Down 01b: Put Up 10b: Contact 11b: Reserved
	5:4		Reserved
	3:0	Touch X Position [11:8]	MSB of Touch X Position in pixels

2.1.5 TOUCHn_XL (n:1-10)

This register describes LSB of the X coordinate of the nth touch point.

Address	Bit Address	Register Name	Description
04h ~ 3Ah	7:0	Touch X Position [7:0]	LSB of the Touch X Position in pixels

2.1.6 TOUCHn_YH (n:1-10)

This register describes MSB of the Y coordinate of the nth touch point and corresponding touch ID.

Address	Bit Address	Register Name	Description
05h ~ 3Bh	7:4	Touch ID[3:0]	Touch ID of Touch Point
3:0	[11:8]	Touch X Position	MSB of Touch Y Position in pixels

2.1.7 TOUCHn_YL (n:1-10)

This register describes LSB of the Y coordinate of the nth touch point.

Address	Bit Address	Register Name	Description
06h ~ 3Ch	7:0	Touch X Position [7:0]	LSB of The Touch Y Position in pixels

2.1.8 ID_G_THGROUP

This register describes valid touching detect threshold.

Address	Bit Address	Register Name	Description
80h	7:0	ID_G_THGROUP	The actual value will be 4 times of the register's value. Default:280/4

2.1.9 ID_G_THPEAK

This register describes valid touching peak detect threshold.

Address	Bit Address	Register Name	Description
81h	7:0	ID_G_THPEAK	Default:60

2.1.10 ID_G_THCAL

This register describes threshold when calculating the focus of touching.

Address	Bit Address	Register Name	Description
82h	7:0	ID_G_THCAL	Default:16

2.1.11 ID_G_THWATER

This register describes threshold when there is surface water.

Address	Bit Address	Register Name	Description
83h	7:0	ID_G_THWATER	Default:60

2.1.12 ID_G_THTEMP

This register describes threshold of temperature compensation.

Address	Bit Address	Register Name	Description
84h	7:0	ID_G_THTEMP	Default:10

2.1.13 ID_G_THDIFF

This register describes threshold whether the coordinate is different from the original.

Address	Bit Address	Register Name	Description
85h	7:0	ID_G_THDIFF	The actual value must be 32timers of the register's value. Default :20

2.1.14 ID_G_CTRL

This register describes the run mode of microcontroller controlled by host

Address	Bit Address	Register Name	Description
86h	0	ID_G_CTRL	0: not auto jump 1:auto jump

2.1.15 ID_G_TIMEENTERMONITOR

This register describes the time delay value when entering monitor status.

Address	Bit Address	Register Name	Description
87h	7:0	ID_G_TIME_ENTERMONITOR	Default :2

2.1.16 ID_G_PERIODACTIVE

This register describes the period of active status, it should not less than 12

Address	Bit Address	Register Name	Description
88h	4:0	ID_G_PERIOD_ACTIVE	Range form 3 to 14,default 12
	7:4		

2.1.17 ID_G_PERIODMONITOR

This register describes period of monitor status, it should not less than 30.

Address	Bit Address	Register Name	Description
89h	7:0	ID_G_PERIOD_MONITOR	Default:40

2.1.18 ID_G_AUTO_CLB_MODE

This register describes auto calibration mode.

Address	Bit Address	Register Name	Description

A0h	7:0	ID_G_AUTO_CLB_MODE	8'h 00: enable auto calibration 8'h ff: disable auto calibration
-----	-----	--------------------	---

2.1.19 ID_G_LIB_VERSION_H

This register describes library version high byte.

Address	Bit Address	Register Name	Description
A1h	7:0	ID_G_LIB_VERSION_H	R: xx

2.1.20 ID_G_LIB_VERSION_L

This register describes library version low byte.

Address	Bit Address	Register Name	Description
A2h	7:0	ID_G_LIB_VERSION_L	R: xx

2.1.21 ID_G_CIPHER

This register describes vendor's chip id.

Address	Bit Address	Register Name	Description
A3h	7:0	ID_G_CIPHER	R: xx

2.1.22 ID_G_MODE

This register describes the interrupt status to host.

Address	Bit Address	Register Name	Description
A4h	7:0	ID_G_MODE	0: Polling mode 1: Trigger mode

2.1.23 ID_G_PMODE

This register describes the power consumption mode of the TPM when in running status.

Address	Bit Address	Register Name	Description
A5h	7:0	ID_G_PMODE	0: active 1: monitor 3: hibernate(deep sleep)

2.1.24 ID_G_FIRMWARE_ID

This register describes the firmware id of the application.

Address	Bit Address	Register Name	Description
A6h	7:0	ID_G_FIRMWARE_ID	R: xx

2.1.25 ID_G_STATE

This register is used to configure the run mode of TPM.

Address	Bit Address	Register Name	Description
A7h	7:0	ID_G_STATE	0: configure 1: work 2: calibration

			3: factory 4: auto calibration
--	--	--	-----------------------------------

2.1.26 ID_G_FT5201ID

This register describes vendor's chip id

Address	Bit Address	Register Name	Description
A8h	7:0	ID_G_FT5201ID	R: xx

2.1.27 ID_G_ERR

This register describes the error code when the TPM is running.

Address	Bit Address	Register Name	Description
A9h	7:0	ID_G_ERR	ERR Code 8'h00:OK 8'h03:chip register writing inconsistent with reading 8'h05:chip start fail 8'h1A:no match among the basic input(such as TX_ORDER) while calibration

2.1.28 ID_G_CLB

This register is used to configure the TPM when Calibration

Address	Bit Address	Register Name	Description
AAh	7:0	ID_G_CLB	Mapping the Array of G_Bank1, total length is NUM_TX+NUM_RX+1. the array address increases 1 after every write.

2.2 Factory Mode

In this mode, CTP will provide some panel related information. Host can get the following information in this mode

Raw data of touch panel

Panel configure related information

Factory Mode Register Map

Address	Name	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Host Access				
00h	DEVIDE_MODE	ST_SCAN	Device Mode[2:0]								RW			
01h	ROW_ADDR	The address of the row to be read									RW			
02h	CLB	Calibration command &status									RW			
03h	ROW_NUM	Panel row number									RW			
04h	COL_NUM	Panel column number									RW			
05h	DRIVER_VOL	Driver voltage of chip									RW			
06h	START_RX	Setting the RX start number									RW			
07h	GAIN	Control the difference value for touching									RW			
08h	ORIGIN_XH	High byte of origin X coordinate									RW			

09h	ORIGIN_XL	Low byte of origin X coordinate	RW	
0Ah	ORIGIN_YH	High byte of origin Y coordinate	RW	
0Bh	ORIGIN_YL	Low byte of origin Y coordinate	RW	
0Ch	RES_WH	High byte of width of resolution	RW	
0Dh	RES_WL	Low byte of width of resolution	RW	
0Eh	RES_HH	High byte of height of resolution	RW	
0Fh	RES_HL	Low byte of height of resolution	RW	
10h	RAWDATA0_H	High byte of raw data 0	R	
11h	RAWDATA0_L	Low byte of raw data 0	R	
12h	RAWDATA1_H	High byte of raw data 1	R	
13h	RAWDATA1_L	Low byte of raw data 1	R	
...		
4Ah	RAWDATA29_H	High byte of raw data 29	R	
4Bh	RAWDATA29_L	Low byte of raw data 29	R	
4Ch	TH_POINT_NUM	Touch point number support	RW	
4Dh	Reserved			
4Eh	Reserved			
4Fh	Reserved			
50h	TX_ORDER_0	TX Order, start from zero	RW	
51h	TX_ORDER_1		RW	
...	RW	
77h	TX_ORDER_39		RW	
78h	ROW0_CAC	Charge Amplifier feedback Capacitance of ROW0	RW	
79h	ROW1_CAC	Charge Amplifier feedback Capacitance of ROW1	RW	
...		
9Fh	ROW39_CAC	Charge Amplifier feedback Capacitance of ROW39	RW	
A0h	COL0_CAC	Charge Amplifier feedback Capacitance of COL0	RW	
...		
BDh	COL29_CAC	Charge Amplifier feedback Capacitance of COL29	RW	
BEh	Reserved			
BFh	ROW0_1_OFFSET	Offset of ROW1	Offset of ROW0	RW
...	
D2h	ROW38_39_OFFSET	Offset of ROW39	Offset of ROW38	RW
D3h	COL0_1_OFFSET	Offset of COL1	Offset of COL0	RW
...	
E1h	COL28_29_OFFSET	Offset of COL29	Offset of COL28	RW
...	...			
FEh	LOG_MSG_CNT	The log MSG count	R	

FFh	LOG_CUR_CHA	Current character of log message, will point to the next character when one character is read.	R
-----	-------------	--	---

2.2.1 DEVICE_MODE

This register is the device mode register, configure it to determine the current mode of the chip.

Address	Bit Address	Register Name	Description
00h	7	ST_SCAN	By default, it is 0; If set to 1, the frame scan begins, and ST_SCAN gets back to 0 once this frame scan finishes. Normally, a full frame scan takes no more than 10ms.
	6:4	Device Mode[2:0]	000b Work Mode 100b Factory Mode – read raw data

2.2.2 ROW_ADDR

This register is the Touch Data status register.

Address	Bit Address	Register Name	Description
01h	7:0	Row address	The address of the row to be read Please delay for more than 100us, then read the raw data

2.2.3 CLB

This register is for the calibration command, calibration status check and calibration result writing.

Address	Bit Address	Register Name	Description
0x02	7:0	CLB	Default value after reset is 0xFF. 0x04: set to start calibration; 0x05: set to start to store calibration result to flash memory.

2.2.4 ROWDATAN_H

This register is the Touch Data status register.

Address	Bit Address	Register Name	Description
(10+2n)h	7:0	High byte of raw data N	High byte of raw data N If N exceeds the column number will return 0xff

2.2.5 ROWDATAN_L

This register is the Touch Data status register.

Address	Bit Address	Register Name	Description
(10+2n+1)h	7:0	Low byte of raw data N	Low byte of raw data N

		If N exceeds the column number will return 0xff
--	--	---

3 CTPM Application Introduction

3.1 Standard Application information of FT5X06

Figure3-1,Figure3-2,Figure3-3 demonstrate the typical FT5x06 application schematic. It consists of FT's Capacitive Touch Panel(CTP), FT5X06 chip, and some peripheral components. According to the size of CTPM, you can choose the numbers of TX and RX needed.

3.1.1 Standard application circuit of FT5206GE1




Figure 3-1 FT5206GE1 typical application schematic

3.1.2 Standard application circuit of FT5306DE4




Figure 3-2 FT5306DE4 typical application schematic

3.1.3 Standard application circuit of FT5406EE8




Figure 3-3 FT5406EE8 typical application schematic

4 Communication between host and CTPM

4.1 Communication Contents

The data Host received from the CTPM through serial interface are different depend on the configuration in Device Mode Register of the CTPM. Please refer to Section 2---CTP Register Mapping.

4.2 I2C Example Code

```
//////////  
// I2C write bytes to device.  
//  
// Arguments: ucSlaveAdr - slave address  
//           ucSubAdr - sub address  
//           pBuf - pointer of buffer  
//           ucBufLen - length of buffer  
//////////  
void i2cBurstWriteBytes(BYTE ucSlaveAdr, BYTE ucSubAdr, BYTE *pBuf, BYTE ucBufLen)  
{  
    BYTE ucDummy; // loop dummy  
    ucDummy = I2C_ACCESS_DUMMY_TIME;
```

FocalTech

```
while(ucDummy--)
{
    if (i2c_AccessStart(ucSlaveAdr, I2C_WRITE) == FALSE)
        continue;
    if (i2c_SendByte(ucSubAdr) == I2C_NON_ACKNOWLEDGE) // check non-acknowledge
        continue;
    while(ucBufLen--) // loop of writting data
    {
        i2c_SendByte(*pBuf); // send byte
        pBuf++; // next byte pointer
    } // while
    break;
} // while
i2c_Stop();
}

///////////////////////////////
// I2C read bytes from device.
//
// Arguments: ucSlaveAdr - slave address
//             ucSubAdr - sub address
//             pBuf - pointer of buffer
//             ucBufLen - length of buffer
/////////////////////////////
void i2cBurstReadBytes(BYTE ucSlaveAdr, BYTE ucSubAdr, BYTE *pBuf, BYTE ucBufLen)
{
    BYTE ucDummy; // loop dummy

    ucDummy = I2C_ACCESS_DUMMY_TIME;
    while(ucDummy--)
    {
        if (i2c_AccessStart(ucSlaveAdr, I2C_WRITE) == FALSE)
            continue;
        if (i2c_SendByte(ucSubAdr) == I2C_NON_ACKNOWLEDGE) // check non-acknowledge
            continue;
        if (i2c_AccessStart(ucSlaveAdr, I2C_READ) == FALSE)
            continue;
        while(ucBufLen--) // loop to burst read
        {
            *pBuf = i2c_ReceiveByte(ucBufLen); // receive byte
            pBuf++; // next byte pointer
        } // while
        break;
    } // while
    i2c_Stop();
}

/////////////////////////////
```

FocalTech

```
// I2C read current bytes from device.  
//  
// Arguments: ucSlaveAdr - slave address  
//           pBuf - pointer of buffer  
//           ucBufLen - length of buffer  
//////////  
void i2cBurstCurrentBytes(BYTE ucSlaveAdr, BYTE *pBuf, BYTE ucBufLen)  
{  
    BYTE ucDummy; // loop dummy  
  
    ucDummy = I2C_ACCESS_DUMMY_TIME;  
    while(ucDummy--)  
    {  
        if (i2c_AccessStart(ucSlaveAdr, I2C_READ) == FALSE)  
            continue;  
        while(ucBufLen--) // loop to burst read  
        {  
            *pBuf = i2c_ReceiveByte(ucBufLen); // receive byte  
            pBuf++; // next byte pointer  
        } // while  
        break;  
    } // while  
    i2c_Stop();  
}
```